

## SPS POWER SUPPLY OPERATING INSTRUCTIONS HELIOS AND OMEGA MODELS

**PLEASE** follow these simple steps before switching on your Sontronics HELIOS or OMEGA power supply



Step 1: The microphone, cable and SPS power supply



Step 2: Connect the supplied audio cable to the MIC IN socket on the front of the SPS power supply and secure the threaded collar



Step 3: The cable is now securely attached



Step 4: Connect the other end of the supplied audio cable to the microphone and secure the threaded collar



Step 5: The cable is securely attached



Step 6: Connect the female XLR plug to the LINE OUT socket on the front of the SPS power supply



Step 7: Connect the supplied IEC mains power cable to the socket on the rear of the SPS power supply



Step 8: Press the red POWER switch on the rear of the SPS power supply. A glowing red LED confirms that power is on

### ⚡ CAUTION ⚡

**Before use:** Connect leads to LINE OUT and MIC IN sockets before turning on POWER switch.

**After use:** Turn off POWER switch before disconnecting leads.